



Zone module with redundant speaker output.

Monitors the amplifier and speaker lines.

This board must be plugged into a slot on the main unit [Vivaldi EN54 EVO+Master](#) or in the expansions to 8 zones [Vivaldi EN54 EVO+Slave](#). To plan in configurations where two loudspeaker lines are required in the same zone (line A).

Certified EN54-16. Certification Nr 0068-CPR-012/2017.

MAIN FEATURES:

- Automatic addressing
- Power management up to 500W RMS
- Monitoring of the loudspeakers lines (dual lines, A+B)
- Monitoring of the amplifiers operation parameters
- Automatic switch to the backup amplifier in case of faults of the main amplifier
- 2 monitored message players, integrated
- Balanced output to feed zone amplifiers
- Status LED
- Dimensions (WxHxD) 85x3,5x134 mm
- Weight 0,1 Kg
- Silver colour

Vivaldi srl ongoing effort to improve its products, reserves the right to make technical and aesthetic changes effectively without obligation to notice

